



Special Instructions - to be followed in addition to the enclosed installation instructions.

Your Waterboot has been designed to the specifications you submitted regarding mast and deck flange/collar circumferences respectively.. To accommodate the offset, with the mast positioned toward the forward or aft end of the partner, we have designed your Waterboot using a little extra material.

The best procedure to follow when installing a Waterboot that has been designed oversized is as follows.

1. First position the Waterboot around the mast and make the closure with the velcro facing aft .
2. Slide the Waterboot down over the collar to where you feel it will make the best seal. Take into consideration how you will seal this bottom edge i.e. electrical tape, clamp, wire tie etc.
3. If there is extra material protruding at the bottom ( which there will likely be) , mark where the Waterboot needs to be trimmed around this bottom edge.
4. Undo the velcro seal and remove the Waterboot to make trimming easier
5. Reinstall and follow the supplied installation instructions to achieve the final seal.